


-Horn  
-Front brake-light switch

-Rear brake-light switch  
-Taillight

-Headlight: low beam  
-Headlight: high beam

IGNITION WIRING



IGNITION. CAPACITOR CHARGING CURRENT: FROM MAGNETO THROUGH BLUE WIRE IN MAGNETO WIRING HARNESS TO UPPER LUG ON HIGH-VOLTAGE COIL. DISCHARGE TIMING PULSE: FROM MAGNETO THROUGH BLACK WIRE IN MAGNETO WIRING HARNESS TO LOWER LUG ON HIGH-VOLTAGE COIL. **IGNITION KILL**: CHARGING CURRENT GOES FROM MAGNETO THROUGH MAGNETO WIRING HARNESS TO HIGH-VOLTAGE COIL (BLUE WIRE); THROUGH IGNITION KILL HARNESS TO IGNITION SWITCH (BLUE WIRE); TO GROUND AT HORN MOUNT (BLACK WIRE), SHORT-CIRCUITING THE CHARGING CURRENT.